

Active cleaning agent for all types of shoes and materials, Suede, Velvet, Leather, Nubuck, Split, Rubber, Linen, Gore-Tex, Nylon, Satin, Espadrille, Plastic, Vinyl

MANUAL:

Shake the product well before use.
Slightly moisten the tip of the bristles of the brush, then dip the brush in the container containing the Shoes Cleaner.
Brush vigorously until the cleanser lathers.
Repeat the steps as many times as necessary to obtain the desired effect.
Let dry. Wipe with a micro-fiber cloth.

PRECAUTIONS FOR USE:

P264 - Wash hands thoroughly after handling. P280 - Wear protective gloves, eye protection. P305+P351+P338 - IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses if the victim wears them and if they can be easily removed. Continue rinsing. P337+P313 - If eye irritation persists: Get medical advice/attention.

Reserved for professional use



Innovative solutions for professionals



contact@uslab.eu • www.uslab.eu