

Active cleaning agent for all types of shoes and materials,
Suede, Velvet, Leather, Nubuck, Split, Rubber, Linen, Gore-Tex, Nylon,
Satin, Espadrille, Plastic, Vinyl

MANUAL:

- Shake the product well before use.
- Slightly moisten the tip of the bristles of the brush, then dip the brush in the container containing the Shoes Cleaner.
 - Brush vigorously until the cleanser lathers.
- Repeat the steps as many times as necessary to obtain the desired effect.
 - Let dry. Wipe with a micro-fiber cloth.

PRECAUTIONS FOR USE:

P264 - Wash hands thoroughly after handling.
P280 - Wear protective gloves, eye protection.
P305+P351+P338 - IF IN EYES: Rinse cautiously with water for several minutes.
Remove contact lenses if the victim wears them and if they can be easily removed. Continue rinsing.

P337+P313 - If eye irritation persists: Get medical advice/attention.

Reserved for professional use



